# TOP AND CONSOLE PARTS

ELECTRIC DRYER

**For Models: LET7646AQ2, LET7646AZ2**
**(Designer White) (Designer Almond)**




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP AND CONSOLE PARTS

**For Models: LET7646AQ2, LET7646AZ2**
**(Designer White) (Designer Almond)**

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | 3397545 | Panel, Rear Console |
| 2 | 688805 | Clip |
| 3 | | Wire, Jumper |
| | 3393811 | Violet |
| | 3393812 | Blue |
| 4 | | Cap, End (L.H.) |
| | 3358531 | White |
| | 3358532 | Almond |
| 5 | 3390647 | Screw, 8−18 x 1/2 |
| 6 | 3353145 | Screw, Console |
| 7 | 689180 | Clip, Retainer |
| 8 | | Cap, End (R.H.) |
| | 3358516 | White |
| | 3358517 | Almond |
| 9 | 3388706 | Resistor, Timer |
| 10 | 349639 | Screen, Lint |
| 11 | | Cover, Lint Screen |
| | 688150 | White |
| | 689310 | Almond |
| 12 | 339229 | Hinge, R.H. |
| | 339230 | Hinge, L.H. |
| 13 | 688983 | Screw, 8−18 x 5/8 |
| 15 | 693995 | Screw (6) |
| 16 | | Top |
| | 3396022 | White |
| | 3396023 | Almond |
| 17 | 694419 | Buzzer, Mini |
| 19 | 3395683 | Connector, (Motor) |
| 20 | 3394427 | Clip |
| 21 | 3397269 | Connector, Timer |
| 22 | 3398137 | Timer, 60 Hz. |
| 30 | 357213 | Nut, Push−In (2) |
| 31 | 3399663 | Harness, Wiring (Includes 690261 Terminal Block) |
| 32 | 3390646 | Screw, 8−18 x 5/16 |
| 39 | 3395395 | Switch, Push−To−Start |
| 48 | | Timer Knob Assembly |
| | 3396146 | White |
| | 3396149 | Almond |
| 53 | 3396295 | Bracket, Control |
| 54 | | Panel, Control |
| | 3397222 | White |
| | 3397242 | Almond |
| 72 | 690853 | Wire, Ground |
| 79 | | Switch, Clean−Touch |
| | 3396239 | White |
| | 3396237 | Almond |
| 81 | | Button, Push To Start |
| | 3396176 | White |
| | 3396177 | Almond |

# LITERATURE AND OPTIONAL PARTS

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| **LITERATURE PARTS** | | |
| | LIT3401083 | Use & Care Guide |
| | LIT3397597 | Instructions, Installation |
| | LIT3401723 | Label, Wiring Diagram |
| **Following May Be Purchased** | | |
| **DO−IT−YOURSELF REPAIR MANUALS** | | |
| | LIT677818 | Dryer |
| **OPTIONAL PARTS NOT INCLUDED** | | |
| **PAINT, TOUCH−UP (1/2oz.)** | | |
| | 72017 | White |
| | 72107 | Almond |
| **PAINT, PRESSURIZED SPRAY (13 oz.)** | | |
| | 350930 | White |
| | 350956 | Almond |
| | 350938 | Primer, Gray |
| **PAINT, BULK (1 qt.)** | | |
| | 799344 | White (Uncut) |
| | 978883 | Almond (Uncut) |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS

**For Models: LET7646AQ2, LET7646AZ2**
**(Designer White) (Designer Almond)**




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS

**For Models: LET7646AQ2, LET7646AZ2**
**(Designer White) (Designer Almond)**

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 2 | 3393008 | Screw, 10−16 x 1/2 |
| 4 | 237979 | Spring, Door (2) |
| 5 | 3396795 | Cover, Terminal Block |
| 6 | 694091 | Screw |
| 7 | 3396805 | Panel, Rear |
| 8 | 3388229 | Clip, Toe Panel (2) |
| 9 | 3357011 | Screw, 10−16 x 1/2 |
| 10 | 347207 | Switch, Door |
| 11 | 98129 | Screw, 6−20 x 1−3/8 (2) |
| 12 | 691581 | Lever, Door Switch Mounting |
| 14 | 687905 | Hinge, R.H. |
| | 687906 | Hinge, L.H. |
| 15 | 343641 | Screw, 10−16 x 1/2 |
| 16 | 3392100 | Foot, Dryer (4) |
| 17 | 342043 | Screw, 10−32 x 1/2 |
| 18 | | Cabinet |
| | 3399585 | White |
| | 3399586 | Almond |
| 19 | 98234 | Clip, Ground |
| 20 | 690363 | Lock, Front Top (2) |
| 21 | | Upper Front Panel |
| | 338012 | White |
| | 689533 | Almond |
| 22 | | Panel, Toe |
| | 692427 | White |
| | 692428 | Almond |
| 23 | 685203 | Clip, Felt Pad |
| 24 | 337189 | Clip, Hinge (2) |
| 27 | 3397713 | Rack, Dry |
| 28 | 238614 | Bumper |
| 29 | 297092 | Clip, Hinge (2) |
| 30 | 690081 | Catch, Door |
| 31 | 98997 | Clip, Harness |
| 33 | 696144 | Strike, Door |
| 35 | 695954 | Door, Rear |
| 36 | | Door Front |
| | 348728 | White |
| | 689330 | Almond |
| 37 | | Handle, Door |
| | 690270 | White |
| | 690271 | Almond |
| 38 | 349464 | Seal & Bearing Assembly |
| 40 | 279393 | Terminal Block Kit For Terminal Block |
| 41 | 690261 | Block, Terminal |
| 51 | 238088 | Hinge, Top (2) |
| 53 | 691366 | Idler & Pulley Assembly |
| 56 | 660996 | Belt, Drive |
| 57 | 348780 | Base, Motor |
| 58 | 172455 | Bolt, 5/16−18 x 3/4 |
| 59 | 3401143 | Pulley, 60 Hz. |
| 62 | 3395652 | Motor Assembly 60 Hz. (Pulley Not Included With Motor) |
| 63 | 660658 | Clamp, Motor |
| | 343481 (Alt.) | |
| | 685441 (Alt.) | |
| 67 | 3390733 | Seal, Door |
| 87 | 697776 | Screw, 10−32 x 1/2 (External Ground) |
| 88 | 693995 | Screw, 10−16 x 1/2 |
| 90 | 279318 | Terminal, Tinned & Brass (3) (Includes Illus. 40) |

# BULKHEAD PARTS

**For Models: LET7646AQ2, LET7646AZ2**
**(Designer White) (Designer Almond)**




| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | 3396352 | Lint Chute Assembly |
| 3 | 3400800 | Screw, 8−18 x 3/4 |
| 5 | 90767 | Screw, 8 x 3/8 |
| 6 | 3399848 | Thermal, Cut−Off (Hi−Limit Thermostat Illus. No.15 Included) |
| 7 | 347139 | Seal, Lint Chute |
| 8 | 3388703 | Washer, Support |
| 10 | 694089 | Wheel, Blower |
| 11 | 695081 | Housing, Blower |
| 12 | 3398161 | Clip |
| 13 | 343641 | Screw, 10−16 x 1/2 |
| 14 | 3397566 | Box, Heater |
| 15 | 3390291 | Thermostat, High Limit 250 °F (121.1 °C) (60 Hz.) |
| 17 | 3398064 | Element, Heater (For 240 Volt Installation) |
| 21 | 279457 | Wire Kit (For Heater Element Wiring Harness Repair) |
| 22 | 3392123 | Seal, Blower |
| 23 | 3392519 | Fuse, Thermal |
| 24 | 3387139 | Thermostat, Internal Bias |
| 41 | 690997 | Ring, Tri |
| 42 | 3399506 | Shaft, L.H. |
| 43 | 3399507 | Shaft, R.H. |
| 44 | 3397588 | Roller, Support |
| 46 | 348197 | Washer, Support |
| 47 | 3359452 | Nut, 3/8−16 |
| 48 | 3399464 | Bulkhead |
| 62 | 3394509 | Ring, Bearing |
| 63 | 97787 | Screw, 11−16 x 7/8 |
| 66 | 3397509 | Seal, Rear Drum |
| 67 | 3396778 | Drum Assembly |
| 68 | 342847 | Baffle, Drum |
| 69 | 3394133 | Bracket, Support |
| 70 | 90296 | Clip |
| 73 | 3398160 | Seal |
| 75 | 696302 | Shield, Exhaust |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST